

## Parts Checklist - Water Base

- |                                       |   |
|---------------------------------------|---|
| A <input type="checkbox"/> Carry Bag  | E <input type="checkbox"/> Wing nut and spring washer |
| B <input type="checkbox"/> Water base | F <input type="checkbox"/> Washer                     |
| C <input type="checkbox"/> Spring     | G <input type="checkbox"/> Spigot                     |
| D <input type="checkbox"/> Spanner    |   |



### Step 1

Extend all four feet out from the bottom of the water base. All feet should be at right angles from each other for maximum stability



### Step 2

Locate large washer, wing nut screw and spring washer. Place the large washer over the top of the spring washer as illustrated



### Step 3

Turn water base over and insert assembled wing nut through the central hole



### Step 4

Tighten down the retaining nut with the spanner provided tighten by hand only do not over tighten



### Step 5

Screw the spring housing and spigot assembly all the way down until flush with the water base. Remove screw plug and fill base with water to complete water base



### Step 6

If required on soft ground additional pegs are provided to aid stability

